



**CMA-350 / 352 INSTALLATION INSTRUCTION  
HEAVY DUTY SWIVEL ADAPTER  
ATTACHES TO 1 ½” NPT**

Unpack carton and check contents:

- (1) Swivel Adapter NPT 1 ½ or NPT 2”                      (1) Allen wrench
- (2) Set Screw

**CAUTION! The overhead support must be capable of supporting five times the weight of the mount and equipment combined. If it cannot is MUST be reinforced.**

**INSTALLATION INSTRUCTIONS**

1. Thread Swivel Adapter onto 1 ½” or 2” NPT pipe at desired overhead location. Tighten securely and install set screw.
2. Thread intermediate length of 1 ½” or 2” NPT pipe and equipment mount onto lower end of swivel adapter. Tighten securely. Install set screw and tighten.

**Adjustments:**

*Yaw: Loosen four (4) fasteners in square plates to rotate lower equipment assembly to desired position; retighten. See additional equipment instructions for roll and pitch.*

