



SLB-004 HANGER BRACKET FOR DAVIS POWERBEAM IV & V

Unpack carton and check contents:

(1)	SLB-004 Plate	(1)	M8 Flatwasher
(2)	M6 x 18 mm Screw	(2)	M6 Flatwasher
(4)	M3 x 16 mm Screw	(4)	M3 Flatwasher
(1)	M8 x 20 mm Screw	(6)	Thumb Nuts

INSTALLATION INSTRUCTIONS

1. Turn projector upside down and place bracket onto projector, lining up the slots in the bracket with the threaded inserts of the projector. The two M6 x 18 mm screws will thread into the two center slots and the four M3 x 16 mm screws will thread into the four corner slots. The M8 x 20 mm screws thread into the slot centered on the rear of the bracket. **CAUTION: When attaching the mount be careful not to overtighten.**
2. See RPA/Smart-Lift™ Instructions.

