



SLB-105 HANGING BRACKET FOR NEC Multisync LT100

Unpack carton and check contents

- | | |
|-----------------------------|--------------------------------|
| (1) RPA-105 Hanging Bracket | (4) M5-8 x 10mm Machine Screws |
| (6) 10-24 Thumb Nuts | (4) Flat Washers |

INSTALLATION INSTRUCTIONS

1. Turn projector upside down on bench.
2. Align four holes of hanging bracket with four M5 Bosses on bottom of projector and install four machine screws (M5-8 x 10mm) with washers. Tighten moderately.
3. Review RPA instructions for final mounting.



