



**SLB-450 HANGER BRACKET  
FOR NVIEW D-400/405/450/455Z; POLAVIEW 220**

Unpack carton and check contents:

- |     |                 |     |                   |
|-----|-----------------|-----|-------------------|
| (1) | SLB-450 bracket | (4) | ¼" Flatwashers    |
| (6) | Thumb Nuts      | (4) | ¼ - 20 x ½" Bolts |

**INSTALLATION INSTRUCTIONS**

1. Turn projector upside down and attach the SLB-450 bracket to the projector using the four (4) ¼ - 20 x ½" bolts and four (4) ¼" flatwashers. When attaching the mount, be careful not to overtighten the screws.
2. See RPA/Smart-Lift™ Instruction sheet for installing to mount.