



**SLB-585 HANGER BRACKET
FOR BOXLIGHT 2500; CHISHOLM GALAXY V470, S600;
CTX EZ PRO 800; 3M MP 8650**

Unpack carton and check contents:

- | | | | |
|-----|---------------|-----|----------------|
| (1) | SLB-585 Plate | (2) | M12 Flatwasher |
| (6) | Thumb Nuts | (2) | M12 x 16 Bolts |
| (4) | M5 x 40M Bolt | (4) | M5 Flatwasher |

INSTALLATION INSTRUCTIONS

1. Turn projector upside down, remove the front leveling feet. Place bracket onto bottom of projector, lining up holes in the bracket with the threaded inserts of projector. Secure bracket to projector using the two (2) M12 bolts and washers and the four (4) M5 bolts and washers.
4. See RPA/Smart-Lift™ Instructions.