



## SLB-680 Hanger Bracket for CTX 600 & 680

Unpack carton and check contents:

(1)	SLB-680	(2)	M4 x 12mm Machine Screws
(2)	10-24 Nylock Nuts	(2)	#10 Flatwashers
(4)	Felt Squares	(1)	U-Form Rod
(2)	M4 Flatwashers	(6)	Thumb Nuts

### Installation Instructions

1. Turn projector upside down.
2. Place the SLB-680 Plate onto the projector bottom so the two (2) thru holes line up with the treaded inserts in the bottom of the projector. Using the M4 machine screws and M4 flatwashers, attach plate to the projector at these two places.
3. Attach the U-Form rod around the projector and up through the two holes in the SLB-680 plate using the #10 flatwashers and 10-24 nylock nuts. **NOTE: This U-Form rod MUST be attached for mount to properly support projector. The U-Form rod will extend more through the clearance hole on the switch side of the projector. This is a correct fit. DO NOT OVERTIGHTEN U-Form rod to projector. Only tighten until a secure fit is achieved. Felt squares are provided to protect projector shell, if desired. They can be attached to the projector or wrapped around the U-Form rod.**
4. See RP and/or Smart-Lift™ Instructions.