



INSTALLATION INSTRUCTIONS SLB-7700 HANGER BRACKET

for Lightware Scout & Dukane Mite-E-Lite 7700

Prior to assembly, unpack carton and verify contents.
If you are missing any of the following components, please contact Customer Service at 1-800/582-6480

- | | | | |
|-----|-------------------------|-----|-------------------------|
| (1) | SLB-7700 Top Bracket | (4) | Thumb Nuts |
| (1) | SLB-7700 U-Form Bracket | (2) | #10 Flatwashers |
| (4) | Felt Pads (1" x 1") | (2) | 10x24 - 1/2 Nylock Nuts |
| (4) | Rubber Spacer Inserts | | |



INSTALLATION INSTRUCTIONS

1. Place two felt pads on the bottom inside center of the u-form bracket, then place the two remaining felt pads one on each side one inch down from the top inside surface of the u-form bracket.
2. Turn projector upside down and place one side of the u-form bracket through the handle of the projector as seen in Fig. 1 below. Then rotate u-form bracket 180° around the back and slide around the projector as seen in Fig. 2 below.
3. Insert the four rubber spacer inserts into the four outer holes in the top bracket on the opposite side of the four threaded studs.
4. Place top bracket on projector lining up the two mounting holes in the top bracket with the two threaded inserts in the u-form bracket, as you adjust bracket to projector so end tabs hang over front and back of projector.
5. Using the two 10x24-1/2 Nylock nuts and #10 flatwashers place washers over threaded inserts start Nylock nuts and tighten. **CAUTION: When attaching the mount be careful not to overtighten.**
6. See RPA/Smart-Lift™ Instructions.



Fig. 1



Fig. 2