

# INSTALLATION INSTRUCTIONS

## SSB-2500, SSM-2500, SLB-2500 and SLM-2500 Interface Brackets


SSB-2500, SSM-2500, SLB-2500 and SLM-2500 Interface Brackets are designed for use with Chief® Series Projector Mounts. See the specific installation instructions provided with the mount for additional installation information.

Unpack carton and verify kit contents. If any listed parts are missing, immediately contact a Chief Customer Service representative.



**WARNING: IMPROPER INSTALLATION CAN LEAD TO EQUIPMENT FALLING CAUSING SERIOUS PERSONAL INJURY AND DAMAGE TO EQUIPMENT! DO NOT substitute hardware. Use only hardware supplied by manufacturer!**

- |                             |  |
|-----------------------------|--|
| (1) Interface Bracket       | (2) Screw, Phillips Pan Head, Machine, M4 x 16mm |
| (4) 10-24 Thumb Nuts **     | (2) Screw, Button Head Cap, M3 x 6mm             |
| (1) All-Points Security Kit | (2) Spacer, Nylon, 1/2" x .218 x 1/4"            |
| (1) 3/32" Security Hex Key  | (2) Washer, #4                                   |
| (1) 5/32" Security Hex Key  | (2) Washer, M4                                   |



\*\*Only used when installing SLB/SSB interface brackets.

### Installation Instructions



**WARNING: OVER TIGHTENING OF SCREWS CAN DAMAGE PARTS AND CAN LEAD TO SERIOUS PERSONAL INJURY AND DAMAGE TO EQUIPMENT! DO NOT over tighten screws when installing interface brackets.**

**NOTE:** Step 1 is only required when installing an SLB/SSB interface bracket. If an SLM/SSM bracket is being installed, proceed to step 2.

1. Screw thumb screws onto 10-24 x 5/8" Phillips pan head screws. DO NOT fully tighten thumb screws at this time.
2. Turn projector upside down on a flat surface.
3. Place 1/4" nylon spacers over the threaded inserts in the front bottom of the projector.
4. Place the interface bracket onto the nylon spacers on the bottom of the projector. Align the mounting holes in the front of the bracket with the nylon spacers and the mounting holes in the rear of the bracket.
5. Position M4 mounting screws with M4 washers through the 1/4" nylon spacers and into the threaded inserts in front bottom of projector. Position M3 mounting screws with #4 washers into the threaded inserts in the rear mounting holes. Tighten all fasteners at this time, securing the bracket to the projector.

**NOTE:** Security screws can be substituted when mounting interface bracket to projector by using the parts and installation instructions in the All-Points Security Kit.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.



Milestone AV Technologies, and its affiliated corporations and subsidiaries (collectively, "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.