



## INSTALLATION INSTRUCTIONS FOR SWR DOORS

**ALL DOORS AND ACCESSORIES THAT REQUIRE GROUNDING MUST HAVE  
GROUND WIRES FIELD INSTALLED. ALL PARTS ARE PROVIDED.**

**NOTE: ALL DOORS AND ACCESSORIES MUST BE GROUNDED FOR UL COMPLIANCE.**

**CAUTION** - TO REDUCE THE RISK OF PERSONAL INJURY AND CONFORM TO  
THE UL LISTING, THESE INSTALLATION INSTRUCTIONS MUST BE FOLLOWED

SWR HINGE



TO INSTALL THE TOP HINGE, THE MALE HALF MOUNTS TO  
RACK FACING DOWN AND FACING UP ON THE BOTTOM HINGE.  
FEMALE HALVES MOUNT TO DOOR.

**Door Grounding** - The door ground stud is located next to the bottom hinge pivot pin. Using the ground wire and kep nut provided, attach one end of the ground wire to the door grounding stud and the other end to the base ground stud located on the inside bottom corner of the rack.  
( Refer to pictures below )

**Rail Grounding** - Using the ground wire, kep nut, and bolt provided, attach one end of the ground wire to teh bottom rail hole and the other end of the ground wire to the base ground stud which is located on the inside bottom corner of the rack.  
( Refer to pictures below )



**NOTE: ALL RACK ASSEMBLY AND INSTALLATION IS TO BE DONE BY QUALIFIED SERVICE PERSONNEL.**