



UPRIGHT PROJECTOR BRACKET UPC-12

Unpack carton and check contents:

- (1) RPA-000
- (1) Hanging Bracket
- (1) Cradle Bracket
- (4) M5 x 12mm Machine Screw
- (6) 10-24 Thumb Nuts
- (4) 10-24 Nylock Nuts
- (4) #10 Flatwashers
- (4) Rubber Spacers Inserts

Installation Instructions:

1. Turn projector upside down on work surface and raise two (2) adjustable feet.
2. Install bracket cradle by carefully spreading vertical legs and sliding down over the rear of the projector and tilting it so slots align with threads of adjustable feet. Retighten adjustable feet moderately, to grab surface of cradle and fix it in position.
3. Turn projector upright on work surface. Place four rubber spacer inserts into larger inner holes in the hanging bracket.
4. Align four .21" diameter outer holes in top hanging bracket with four 10-24 x .50" long studs in cradle and fasten assembly with four (4) 10-24 nylock nuts and flat washers. Tighten moderately.
5. Review RPA instructions for final mounting.

The UPC-12 will fit the PANASONIC PT-L 592, 595, 795.

CAUTION: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY!
 The overhead support **must** be capable of supporting **five times** the weight of the mount **and** equipment combined. If it cannot support this weight, the ceiling **must** be reinforced.

