



UPC-16 UPRIGHT PROJECTOR BRACKET FOR FUJITSU LPF-7200, LPF-7205, LPF-7700, CHRISTIE VIVID GREEN,

Unpack carton and check contents

- | | |
|---------------------------|--------------------------------|
| (1) RPA-000 | (6) 10-24 Thumb Nuts |
| (1) Hanging Bracket | (4) 10-24 Nylock Nuts |
| (1) Cradle Bracket | (4) # 10 Flat Washers |
| (4) Rubber Bumper Spacers | (4) 1" Self Adhesive Felt Pads |

Installation Instructions RPA Plate and Cradle Assembly

1. Find the four self adhesive felt pads and the cradle bracket and place two felt pads on each side of the square filter cutout in cradle bracket to protect the projector from scratching or marring.
2. Turn projector upside down on work surface, carefully spread vertical legs of cradle down over sides of projector and align the filter hole cut out in the bracket with the filter door on the bottom side of the projector with the opening in the face of cradle. **CAUTION: When installing cradle bracket spread sides carefully, and enough so sides of cradle bracket don't scratch or mar the paint on the sides of your projector.**
3. Turn projector upright on work surface.
4. Install four 1/2" diameter by 1/4" long rubber bumper spacers in four .28" diameter, inner holes of hanging bracket. Push bumpers into holes with larger diameter facing projector surface.
5. Align four .21" diameter outer holes in hanging bracket with four 10-24 x 1/2" long studs in cradle and fasten assembly with four 10-24 nylock nuts and flat washers.
6. Review RPA instructions for final mounting.