

# INSTALLATION INSTRUCTIONS

## ASE, ASU, MSE & MSU ADJUSTA-SET™ UNIVERSAL SLIDE PROJECTOR STAND

Prior to assembly, unpack carton completely and verify contents.

If you are missing any of the following components, please contact Customer Service at 1-800/582-6480

BEFORE PROCEEDING, READ INSTALLATION INSTRUCTIONS COMPLETELY

1. Remove all packaging material.
2. Loosen small lock knobs on each side of projector cradle and level cradles by rotating larger knobs forward.
3. For all Models other than EK-III projectors, see additional instructions.
4. For EK-III projectors, perform the following:
  - a. Retract all adjustable feet of projector fully.
  - b. Place projector into cradle
  - c. Slide projector forward until the cradle stops against the front stop bracket.
  - d. Secure the projector to the stand by tightening the hold down knob through the hole (see Figure 1) snugly into the threaded socket in the base of each projector and tighten rear brackets using rear hold down knob.




Figure 1



**CHIEF MANUFACTURING INC.**  
1-800-582-6480 952-894-6280 FAX 952-894-6918  
8401 EAGLE CREEK PKWY, STE. 700  
SAVAGE, MINNESOTA 55378 USA

8803-000056 REV. A  
2004 Chief Manufacturing  
[www.chiefmfg.com](http://www.chiefmfg.com)  
12/04