
INSTALLATION INSTRUCTIONS



Ceiling Plates

CHKISTIE®

CMA101

CMA101 Installation Instructions

DISCLAIMER

Christie Digital Systems, Inc. and its affiliated corporations and subsidiaries (collectively "Christie"), intend to make this manual accurate and complete. However, Christie makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Christie makes no representation of warranty, expressed or implied, regarding the information contained herein. Christie assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Christie® is a registered trademark of Digital Systems, Inc. All rights reserved.



IMPORTANT SAFETY INSTRUCTIONS!


WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.



CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.



WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.





WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components attached to the CMA mount does not exceed 500 lbs (226.8 kg).

NOTE: The weight capacity of the CMA mounts may be LIMITED to the lowest weight capacity of any other component located between the ceiling plate and the projector/display.



WARNING: Use this mounting system only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.



WARNING: Never operate this mounting system if it is damaged. Return the mounting system to a service center for examination and repair.



WARNING: Do not use this product outdoors.

IMPORTANT!: These CMA mounts are designed for attachment to a 2" x 4" or larger wood framework ceiling.




WARNING: Do NOT attach to vertical mounting surfaces such as walls or angled ceilings!

--SAVE THESE INSTRUCTIONS--

TOOLS REQUIRED FOR INSTALLATION




PARTS



Installation Instructions CMA101

DIMENSIONS



LEGEND

	Tighten Fastener	Pencil Mark
	Apretar elemento de fijación	Marcar con lápiz
	Befestigungsteil festziehen	Stiftmarkierung
	Apertar fixador	Marcar com lápis
	Serrare il fissaggio	Segno a matita
	Bevestiging vastdraaien	Potloodmerkteken
	Serrez les fixations	Marquage au crayon
	Loosen Fastener	Drill Hole
€	Aflojar elemento de fijación	Perforar
	Befestigungsteil lösen	Bohrloch
	Desapertar fixador	Fazer furo
	Allentare il fissaggio	Praticare un foro
	Bevestiging losdraaien	Gat boren
	Desserrez les fixations	Percez un trou
	Phillips Screwdriver	Adjust
	Destornillador Phillips	Ajustar
	Kreuzschlitzschraubendreher	Einstellen
	Chave de fendas Phillips	Ajustar
	Cacciavite a stella	Regolare
	Kruiskopschroevendraaier	Afstellen
	Tournevis à pointe cruciforme	Ajuster
O O	Open-Ended Wrench	Remove
	Llave de boca	Quitar
	Gabelschlüssel	Entfernen
	Chave de bocas	Remover
	Chiave a punte aperte	Rimuovere
	Steeksleutel	Verwijderen
	Clé à fourche	Retirez
	By Hand	Optional
	A mano	Opcional
	Von Hand	Optional
	Com a mão	Opcional
	A mano	Opzionale
	Met de hand	Optie
	À la main	En option
	Hex-Head Wrench	Security Wrench
	Llave de cabeza hexagonal	Llave de seguridad
	Sechskantschlüssel	Sicherheitsschlüssel
	Chave de cabeça sextavada	Chave de segurança
	Chiave esagonale	Chiave di sicurezza
	Zeskantsleutel	Veiligheidssleutel
	Clé à tête hexagonale	Clé de sécurité

Installation Instructions CMA101

INSTALLATION AND ASSEMBLY

These CMA mounts are designed for attachment to a 2" x 4" or larger wood framework ceiling.



WARNING: Do NOT attach to vertical mounting surfaces such as walls or angled ceilings!



WARNING: IMPROPER INSTALLATION CAN LEAD TO LIFT FALLING CAUSING SEVERE PERSONAL INJURY OR DAMAGE TO EQUIPMENT! It is the installer's responsibility to make certain the structure to which the mount is being attached is capable of supporting five times the weight of the CMA mount and all attached equipment. Reinforce the structure as required before installing the mount.

NOTE: The following instructions assume a suitable mounting structure and surface exists prior to installation.

Installing to a Wood Framework (Joists)

 Use 5/16-18" x 2-1/2" (minimum) Grade 2 lag screws (not provided) to secure CMA mount to the joists or wood framework, using the bolt holes noted. See Figure 1 for dimensions details.

NOTE: If using only two bolt holes for mounting, two opposing holes must be used.




Figure 1

Attaching Column to CMA Mount (non-security)

- Install 1-1/2" NPT or NPSM following ANSI/ASME B1.20.1 (Schedule 40, 0.154" minimum thickness aluminum - ASTM B221) threaded extension column (not included) into threaded collar until tight, with a minimum of four threads engaged. (See Figure 2)
- Install 5/16-18 x 3/8" set screw (B) into hole on ceiling plate (A) to secure pipe to mount. (See Figure 2)




Figure 2

Install the ceiling mount and projector to the CMA mount using installation instructions included with the ceiling mount.

Attaching Column to CMA Mount (security)

- Install 1-1/2" NPT or NPSM following ANSI/ASME B1.20.1 (Schedule 40, 0.154" minimum thickness aluminum - ASTM B221) threaded extension column (not included) into threaded collar until tight, with a minimum of four threads engaged. (See Figure 2)
- Install #10-24 x 1/4" button head security screw (C) into hole on ceiling plate (A) to secure pipe to mount. (See Figure 2)
- Install the ceiling mount and projector to the CMA mount using installation instructions included with the ceiling mount.

CMA101 Installation Instructions

Installation Instructions CMA101

Christie Digital Systems USA, Inc.

USA

Toll Free: 1-800-221-8025

PH: 519-744-8005 FX: 519-749-3302

Monday - Friday 8:00 am - 8:00 pm EST

Canada

Toll Free: 1-800-221-8025

PH: 519-744-8005 FX: 519-749-3302

Monday - Friday 8:00 am - 8:00 pm EST

Chile

PH: 519-744-8005 FX: 519-749-3302

Monday - Friday 8:00 am - 8:00 pm EST

Singapore

PH: +65 6877-8737 FX: +65 6877-8747

Monday - Friday 9:00 am - 5:00 pm SST

China

PH: +86 10 6561 0240 FX: +86 10 6561 0546

Monday - Friday 9:00 am - 5:00 pm CST

Japan

PH: 81-3-3599-7481 FX: 81-3-3599-7482

Monday - Friday 9:00 am - 5:00 pm JST

South Korea

PH: +82 2 702 1601 FX: +82 2 702 1602

Monday - Friday 9:00 am - 5:00 pm KST

India

PH: +91 (080) 41468940 FX: +91 (080) 41468949

Monday - Friday 9:00 am - 5:00 pm IST

United Kingdom

PH: +44 (0) 118 977 8111 FX: +44 (0) 118 977 8112

Monday - Friday 8:30 am - 5:00 pm GMT

France

PH: +33 (0)1 41 21 44 10 FX: +33 (0)1 41 21 00 36

Monday - Friday 10:00 am - 6:00 pm CEST

Germany

PH: +49 2161 56620 22 FX: +49 2161 6645 46

Monday - Friday 8:30 pm - 5:30 pm CEST

Eastern Europe

PH: +44 (0) 118 977 8111 FX: +44 (0) 118 977 8112

Monday - Friday 8:30 am - 5:00 pm GMT

Middle East

PH: +44 (0) 118 977 8111 FX: +44 (0) 118 977 8112

Monday - Friday 8:30 am - 5:00 pm GMT

Spain

PH: + 34 91 633 9990 FX: + 3491 633 9991

Monday - Friday 9:00 am - 5:00 pm CEST

Italy

PH: +39 (0)2 9902 1161 FX: +39 (0)2 9902 2641

Monday - Friday 9:00 am - 5:00 pm CEST

Africa

PH: +44 (0) 118 977 8111 FX: +44 (0) 118 977 8112

Monday - Friday 8:30 am - 5:00 pm GMT



8800-002249 Rev00 11/12 Christie Digital Systems USA, Inc.

10550 Camden Drive Cypress, CA 90630 www.christiedigital.com

