



CMA-120 ANGLED CEILING PLATE

INSTALLATION INSTRUCTIONS

The CMA-120 Angled Ceiling Plate is designed for ease of installation with any height angled drop ceiling. The CMA-120 allows you to suspend a video projector from an angled ceiling.

WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY! All components must be securely fastened to each other and to the ceiling, **AND** the ceiling **MUST** be capable of supporting 700 lbs. (318 kg) of weight. If it cannot, the ceiling **MUST** be reinforced.

1. Securely install the Angled Ceiling Plate “A” to the ceiling.
NOTE: Be sure ceiling meets the requirements outlined above.
2. To adjust level position of bottom plate “B”; loosen “C” and adjust to level position. Retighten bolt “C” securely.
3. To attach either the CMA-100 or CMA-110 to the CMA-120 line up the holes in the bottom plate “B” with the ceiling plate on the CMA-100 or CMA-110. Additional instructions are included with the CMA-100 and CMA-110.