



The Chief HB050V video projector ceiling mount is designed to provide fast, simple and secure installation of the Vidikron Vision. Special roll, pitch, yaw and horizontal adjustments simplify projection positioning for image alignment. The HB050V mount also has positive registration lock so that the projector may be removed without losing projector mount registration.

WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY! All components must be securely fastened to each other and to the ceiling, AND the ceiling MUST be capable of supporting 5 times the total weight of the installation. If it cannot, the ceiling MUST be reinforced.

Unpack and check contents:

/1	D - 1	: 1:	4 1	1-1	(10)	ш10 fl-4
(1) Deluxe	e cemng mou	int housing a	ssembly.	(12)	#10 washers, flat

(1) Vidikron mounting bracket (6) 10 - 32 x 3/8" Screws, PH, Phillips

(4) 5/16" Flange Nuts (6) 10 - 32 x 2" Screws, PH, Phillips

(6) Nylon Spacer .50" OD X .26"ID X 1.625 TL

INSTALLATION INSTRUCTIONS

- 1. Turn your projector upside down.
- 2. Place the (6) Nylon Spacers over the six threaded inserts in the bottom of the projector.
- 3. Place the Vidikron mounting bracket on the six nylon spacers on the bottom of the projector. The triangle in the front center of the bracket should be facing the front of your projector and the six holes in the bracket line up with the six threaded inserts in the bottom of the projector.
- 4. Slide the (12) #10 washers, two on each (6) 10-32 x 2" Screw and install them into the six threaded inserts in the projector. Securely tighten all six mounting screws at this time.
- 5. Be sure that the method of support you are using for the VCM ceiling mount is securely installed to the ceiling. If not, the ceiling must be reinforced. Improper installation may result in serious personal injury.
- 6. Attach the VCM housing to your method of support and tighten firmly so the VCM housing is square to the screen.

PRECAUTION: Installing a ceiling mount requires the presence of two persons familiar with mechanical installations. A third assistant is recommended.

6. With the help of your assistants, lift the projector and install it to the four studs extending from the mounting plate. Be sure the Vidikron mounting plate is seated in slots. **Tighten securely** using the (4) 5/16" flange nuts.

For projector alignment see attached sheet.

8803-000069 03/02/06