



HB90C
VIDEO PROJECTOR CEILING MOUNT
FOR CHRISTIE VISA S3, S4, S5, X3, X4, X5, CHRISTIE ROADSTER S4, S6, X4, X6,
CHIRTIE PRODIGI X6

The Chief HB64C video projector ceiling mount is designed to provide fast, simple and secure installation of the Christie Visa S3, S4, S5, X3, X4, X5, Christie Roadster S4, S6, X4, X6, CHIRTIE PRODIGI X6. Special roll, pitch, yaw and horizontal adjustments simplify projection positioning for image alignment. The HB63B mount also has positive registration lock so that the projector may be removed without losing projector mount registration.

WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY! All components must be securely fastened to each other and to the ceiling, **AND** the ceiling **MUST** be capable of supporting 5 times the total weight of the installation. If it cannot, the ceiling **MUST** be reinforced.

Unpack and check contents:

- | | | | |
|-----|--|-----|---------------------------|
| (1) | Deluxe ceiling mount housing assembly. | (4) | M12 Flatwashers |
| (1) | Christie mounting bracket | (4) | M12 X 20mm hex head bolts |
| (4) | 5/16" flange nuts | | |

INSTALLATION INSTRUCTIONS

1. Turn your projector upside down.
2. Place the Christie mounting bracket on the projector so the hooks are closer to the front of the projector and the four mounting holes line up.
3. Place the (4) M12 flatwashers over the four mounting holes and screw in the (4) M12 X 20mm hex head bolt finger tight. **Using the proper wrench securely tighten all four mounting bolts at this time.**
4. Be sure that the method of support you are using for the VCM ceiling mount is securely installed to the ceiling. If not, the ceiling must be reinforced. Improper installation may result in serious personal injury.
5. Attach the VCM housing to your method of support and tighten firmly so the VCM housing is square to the screen.

PRECAUTION: *Installing a ceiling mount requires the presence of two persons familiar with mechanical installations. A third assistant is recommended.*

6. With the help of your assistants, lift the projector and install it to the studs extending from the mounting plate. Be sure the Christie mounting plate is seated in slots. **Tighten securely** using the (4) 5/16" flange nuts.

For projector alignment see attached sheet.