

HB-"ALICE"

VIDEO PROJECTOR HANGING BRACKET FOR AMPRO "ALICE"

The HB-"Alice" Hanging Bracket is designed to attach the Ampro "Alice" projector to the EVCM-100 Electric Ceiling Mount or the VCM-"Alice" Deluxe Ceiling Mount.

WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY!

All components must be securely fastened to each other and to the ceiling, **AND** the ceiling **MUST** be capable of supporting 5 times the suspended load of the unit you are using. If it cannot, the ceiling **MUST** be reinforced.

Unpack and check contents:

- (1) Mounting Bracket
- (6) $\frac{5}{16}$ -18 x $\frac{5}{8}$ Hexhead Bolts
- (4) $\frac{5}{16}$ -18 Flange Nut
- (6) $\frac{5}{16}$ Flat Washers
- (6) $\frac{5}{16}$ Split lockwashers

INSTALLATION INSTRUCTIONS

1. Turn your projector upside down.
2. Attach the mounting plate to the projector using the (6) $\frac{5}{16}$ -18 x $\frac{5}{8}$ " Hexhead bolts and washers. **Securely tighten bolts.**
3. Be sure the method of support you are using for the VCM-"Alice" ceiling mount is securely installed to the ceiling. If not, the ceiling must be reinforced. Improper installation may result in serious personal injury.
4. Attach the VCM housing to your method of support and tighten firmly so the VCM housing is square to the screen.

PRECAUTION: Installing the ceiling mount requires the presence of two person familiar with mechanical installations. A third assistant is recommended.

5. With the help of your assistants, lift the projector and install it to the studs extending from the mounting plate. Be sure the mounting plate is seated in slots. **Tighten securely** using the $\frac{5}{16}$ -18 flange nuts.

FOR PROJECTOR ALIGNMENT SEE ATTACHED SHEET.