

LCD-100CI CEILING MOUNT FOR AMPRO 100

The Chief LCD-100CI Ceiling Mount is designed for the Ampro 100 projector. The LCD-100CI can be attached with standard NPT 1½” pipe column or with Chief’s CMA-100, Adjustable Column & Ceiling Plate or CMA-110, Flat Ceiling Plate.

Unpack carton and check contents:

- | | | | |
|-----|--|-----|---|
| (1) | LCD-100CI Mount | (1) | ⁵ / ₃₂ ” Allen Wrench |
| (1) | ⁵ / ₁₆ -18 Set Screw | (1) | ³ / ₁₆ ” Allen Wrench |
| (4) | M6 x 18mm Bolt | | |

WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY!
All components must be securely fastened to each other and to the ceiling, **AND** the ceiling **MUST** be capable of supporting 4 times the suspended load of the unit you are using. If it cannot, the ceiling **MUST** be reinforced.

INSTALLATION INSTRUCTIONS

1. The LCD-100CI Mount may be packed with the threaded collar in a downward position. After removing the mount from the carton, using the ³/₁₆” wrench, loosen the four allen head bolts, (see 2) and position the collar upward.
2. Attach the mount to your projector. Securely tighten all fasteners.
3. Install the LCD-100CI Mount to your method of ceiling support and tighten. Install the ⁵/₁₆-18 set screw into the threaded collar and tighten.

TO ADJUST YAW:

Loosen set screw (see 1) and turn collar to desired yaw; tighten set screw.

TO ADJUST PITCH:

Loosen the four allen head bolts (see 2) and adjust to desired pitch; tighten bolts.