

LCD CEILING MOUNTS
MODEL LCD-110C, LCD-120C & LCD-130C

INSTALLATION INSTRUCTIONS

Chief's LCD series ceiling mounts provide optimum operating flexibility for most popular LCD projectors. A wide range of adjustments, including roll, pitch and yaw make image registration quick and precise. All of the LCD ceiling mounts can be attached with standard NPT 1½" pipe column or with Chief's CMA-100 or CMA-110.

Unpack carton and check contents:

- 1 LCD Frame
- 1 LCD Cradle
- 1 5/16-18 Set screw
- 1 5/32" Allen wrench
- 4 ¼-20 Nylock Nuts

<p>WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY! All components must be securely fastened to each other and to the ceiling, AND the ceiling MUST be capable of supporting 4 times the suspended load of the unit you are using. If it cannot, the ceiling MUST be reinforced.</p>

1. Attach the LCD cradle to the LCD frame by installing the cradle with the studs into the cup plate on the LCD frame. Secure cradle to frame by using the nylock nuts, tighten the nuts securely.
2. Attach the LCD mount to your method of support and tighten securely. Install the set screw and tighten securely to lock the mount to column.
3. Place projector into cradle and secure with safety strap.
4. To adjust roll, pitch and yaw, turn knob clockwise to loosen; adjust your projector and then turn knob counter clockwise to tighten.

<p>8804-000051 12/03</p>
