

## LCD-5100CI CEILING MOUNT FOR PROXIMA MP 5100 AND 3M MP 8030

The Chief LCD-5100CI Ceiling Mount is designed for the Proxima MP 5100 and 3M MP 8030 projectors. The LCD-5100CI can be attached with standard NPT 1½” pipe column or with Chief’s CMA-100, Adjustable Column & Ceiling Plate or CMA-110, Flat Ceiling Plate.

Unpack carton and check contents:

(1)	LCD-5100CI Mount	(1)	5/32” Allen Wrench
(1)	5/16-18 Set Screw	(1)	3/16” Allen Wrench
(8)	#10 Flatwashers	(8)	8 - 32 x 5/8” Machine Screws

<p><b>WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY!</b> All components must be securely fastened to each other and to the ceiling, <b>AND</b> the ceiling <b>MUST</b> be capable of supporting 4 times the suspended load of the unit you are using. If it cannot, the ceiling <b>MUST</b> be reinforced.</p>
---

### INSTALLATION INSTRUCTIONS

1. Turn projector upside down.
2. Attach the mount to your projector using the #10 flatwashers and screws. Securely tighten all fasteners.
3. Install the LCD-5100CI Mount to your method of ceiling support and tighten. Install the 5/16-18 set screw into the threaded collar and tighten.

*TO ADJUST YAW:*

Loosen set screw (see 1) and turn collar to desired yaw; tighten set screw.

*TO ADJUST PITCH:*

Loosen the four allen head bolts (see 2) and adjust to desired pitch; tighten bolts.