

## LCD-585CI CEILING MOUNT

The Chief LCD-585CI Ceiling Mount is designed for your LCD projector. The LCD-585CI can be attached with standard NPT 1½” pipe column or with Chief’s CMA-100, Adjustable Column & Ceiling Plate or CMA-110, Flat Ceiling Plate.

Unpack carton and check contents:

(1)	LCD-585CI Mount	(1)	3/16” Allen Wrench
(1)	5/16-18 Set Screw	(4)	M5 x 40mm Bolt
(1)	5/32” Allen Wrench	(4)	M5 Flatwashers

**WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY!**  
All components must be securely fastened to each other and to the ceiling, **AND** the ceiling **MUST** be capable of supporting 4 times the suspended load of the unit you are using. If it cannot, the ceiling **MUST** be reinforced.

## INSTALLATION INSTRUCTIONS

1. Attach the mount to your projector using the four (4) metric bolts and washers. Securely tighten all fasteners.
2. Install the LCD-585CI Mount to your method of ceiling support and tighten. Install the 5/16-18 set screw into the threaded collar and tighten.

### *TO ADJUST YAW:*

Loosen set screw (see 1) and turn collar to desired yaw; tighten set screw.

### *TO ADJUST PITCH:*

Loosen the four allen head bolts (see 2) and adjust to desired pitch; tighten bolts.