

## LCD-620CI CEILING MOUNT FOR INFOCUS LP 610/620

The Chief LCD-620CI Ceiling Mount is designed for the Infocus LP 610/620 projector. The LCD-620CI can be attached with standard NPT 1½” pipe column or with Chief’s CMA-100, Adjustable Column & Ceiling Plate or CMA-110, Flat Ceiling Plate.

Unpack carton and check contents:

|     |                   |     |                           |
|-----|-------------------|-----|---------------------------|
| (1) | LCD-620CI Mount   | (1) | 5/32” Allen Wrench        |
| (1) | 5/16-18 Set Screw | (1) | 3/16” Allen Wrench        |
| (4) | #10 Flatwasher    | (4) | 10-32 x ½” Machine Screws |

**WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY!**  
All components must be securely fastened to each other and to the ceiling, **AND** the ceiling **MUST** be capable of supporting 4 times the suspended load of the unit you are using. If it cannot, the ceiling **MUST** be reinforced.

### INSTALLATION INSTRUCTIONS

1. Turn projector upside down.
2. Attach the mount to your projector using the #10 flatwashers and screws. Securely tighten all fasteners.
3. Install the LCD-620CI Mount to your method of ceiling support and tighten. Install the 5/16-18 set screw into the threaded collar and tighten.

#### *TO ADJUST YAW:*

Loosen set screw (see 1) and turn collar to desired yaw; tighten set screw.

#### *TO ADJUST PITCH:*

Loosen the four allen head bolts (see 2) and adjust to desired pitch; tighten bolts.