

LCD-950CI CEILING MOUNT
FOR SHARP XG-1000U, XG-E850U, XG-H440U, XG-E800U

The Chief LCD-950CI Ceiling Mount is designed for the Sharp XG-1000U, XG-E850U, XG-H440U, XG-E800U projectors. The LCD-950CI can be attached with standard NPT 1½” pipe column or with Chief’s CMA-100, Adjustable Column & Ceiling Plate or CMA-110, Flat Ceiling Plate.

Unpack carton and check contents:

(1)	LCD-950CI Mount	(4)	¼” Flatwasher
(4)	¼-20 x ¾” Bolts	(4)	Corner Bracket (steel)
(1)	⅝-18 Set Screw	(1)	⅝-32” Allen Wrench
		(1)	⅜-16” Allen Wrench

WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY!
All components must be securely fastened to each other and to the ceiling, **AND** the ceiling **MUST** be capable of supporting 4 times the suspended load of the unit you are using. If it cannot, the ceiling **MUST** be reinforced.

INSTALLATION INSTRUCTIONS

1. Turn projector upside down.
2. Remove the four plastic corner brackets from the projector, saving the screws for re-use. (The four plastic corner brackets should be saved if the projector may be used later on a table.)
3. Attach the steel corner brackets to the proper corners on the projector and secure with the screws removed in step 1.
4. Attach the mounting bracket to the projector and secure using the ¼-20 x ¾” bolts and washers.

TO ADJUST YAW:

Loosen set screw (see 1) and turn collar to desired yaw; tighten set screw.

TO ADJUST PITCH:

Loosen the four allen head bolts (see 2) and adjust to desired pitch; tighten bolts.

8804-000060
12/03