

INSTALLATION INSTRUCTIONS

MSP-DCCCINT4504 Interface Bracket

The MSP-DCCCINT4504 Interface Bracket is designed for use with Chief® Series Projector Mounts. See the specific installation instructions provided with the mount for additional installation information.

Unpack carton and verify kit contents. If any listed parts are missing, immediately contact a Chief Customer Service representative.



WARNING: IMPROPER INSTALLATION CAN LEAD TO EQUIPMENT FALLING CAUSING SERIOUS PERSONAL INJURY AND DAMAGE TO EQUIPMENT! DO NOT substitute hardware. Use only hardware supplied by manufacturer!

(1) Interface Bracket

(1) MSP-DCCC4504 Security Hardware Kit

(1) MSP-DCCC4504 Interface Hardware Kit




Figure 1

Installation Instructions



WARNING: OVER TIGHTENING OF SCREWS CAN DAMAGE PARTS AND CAN LEAD TO SERIOUS PERSONAL INJURY AND DAMAGE TO EQUIPMENT! DO NOT over tighten screws when installing interface brackets.

1. Screw thumb screws (from MSP-DCCC4504 Security Hardware Kit) onto 10-24 x 5/8" Phillips pan head screws. DO NOT fully tighten thumb screws at this time.
2. Turn projector upside down on a flat surface.
3. Place the interface bracket onto the bottom of the projector, aligning the mounting holes in the bracket with the threaded inserts in the bottom of the projector and ensuring that triangle in bracket points towards front of projector.
4. Use three M3 x 16mm flat head screws and three spacers (all from MSP-DCCC4504 Interface Hardware Kit) to secure the interface bracket to the projector. (See Figure 1)

NOTE: The hardware needed for attachment will vary dependent on projector model. See installation cards included with Interface Hardware Kit and Security Hardware Kit.

NOTE: Security screws can be substituted when mounting Interface bracket to projector by using the parts and installation instructions in the Security Hardware Kit.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.



Milestone AV Technologies, and its affiliated corporations and subsidiaries (collectively, "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.