
# INSTALLATION INSTRUCTIONS



**PRO-MOTION CEILING AND WALL MOUNT** 



**MSP-PRORLT** 

#### **DISCLAIMER**

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.




**WARNING:** A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.



**CAUTION:** A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.



**WARNING:** Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.





component.


**WARNING:** Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components located between the MSP-PRORLT up to (and including) the display/projector does not exceed 175 lbs (79.4 kg).

Installation Instructions MSP-PRORLT


# **LEGEND**

	Tighten Fastener	Pencil Mark
G	Apretar elemento de fijación	Marcar con lápiz
	Befestigungsteil festziehen	Stiftmarkierung
	Apertar fixador	Marcar com lápis
	Serrare il fissaggio	Segno a matita
	Bevestiging vastdraaien	Potloodmerkteken
	Serrez les fixations	Marquage au crayon
$\odot$	Loosen Fastener  Aflojar elemento de fijación	Drill Hole Perforar
	Befestigungsteil lösen	Bohrloch
		<b>—</b>
	Desapertar fixador	Fazer furo
	Allentare il fissaggio	Praticare un foro
	Bevestiging losdraaien	Gat boren
	Desserrez les fixations	Percez un trou
<b>(</b>	Phillips Screwdriver	Adjust
	Destornillador Phillips	Ajustar
	Kreuzschlitzschraubendreher	Einstellen
	Chave de fendas Phillips	Ajustar
	Cacciavite a stella	Regolare
	Kruiskopschroevendraaier	Afstellen
	Tournevis à pointe cruciforme	Ajuster
	Open-Ended Wrench	Remove
	Llave de boca	Quitar
	Gabelschlüssel	Entfernen
	Chave de bocas	Remover
	Chiave a punte aperte	Rimuovere
	Steeksleutel	Verwijderen
	Clé à fourche	Retirez
	By Hand	Optional
	A mano	Opcional
	Von Hand	Optional
	Com a mão	Opcional
	A mano	Opzionale
	Met de hand	Optie
	À la main	En option
3	Hex-Head Wrench	Security Wrench
	Llave de cabeza hexagonal	Llave de seguridad
	Sechskantschlüssel	Sicherheitsschlüssel
	Chave de cabaca caytayada	Chave de segurança
l l	Chave de cabeça sextavada	
	Chiave de cabeça sextavada  Chiave esagonale	Chiave di sicurezza
		Chiave di sicurezza  Veiligheidssleutel

## **TOOLS REQUIRED FOR INSTALLATION**



## **PARTS**



Installation Instructions MSP-PRORLT

#### **ASSEMBLY AND INSTALLATION**

## **Mounting to Ceiling**

- Install four 5/16-18 x 3/4" button head cap screws through RLT Bracket (A), LP tilt mount (C), 1/4" washers (F) and into 5/16-18" lock nuts(E). (See Figure 1)
- Use 3/16" hex key and 1/2" wrench to tighten screws to lock nuts. (See Figure 1)
- Connect mounting pipe (not included) to pipe adapter in RLT bracket by turning it until it is secured as tightly as possible. (See Figure 1)
- 4. Secure mounting pipe to pipe adapter using 5/16-18" set screw (G). (See Figure 1)
- 5. Refer to ceiling plate manual for details on connecting ceiling flange (B) to ceiling and mounting pipe.

## **Mounting to Wall**

 Install LP tilt mount (C) directly to wall according to LP tilt mount manual.

#### **Display Installation**



**WARNING:** Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components located between the MSP-PRORLT up to (and including) the display/projector does not exceed 175 lbs (79.4 kg).

 Refer to LP tilt mount installation instructions to mount display.




Figure 1

Installation Instructions MSP-PRORLT



Our Mounts. Your Vision.

Chief Manufacturing, a products division of Milestone AV Technologies

8832-000280 Rev01 ©2010 Milestone AV Technologies, a Duchossois Group Company www.chiefmfg.com 06/10 **USA/International** 

**Europe** 

**Asia Pacific** 

A 8401 Eagle Creek Parkway, Savage, MN 55378

**P** 800.582.6480 / 952.894.6280

**F** 877.894.6918 / 952.894.6918

A Fellenoord 130 5611 ZB EINDHOVEN, The Netherlands

**P** +31 (0)40 2668620

**F** +31 (0)40 2668615

A Office No. 1 on 12/F, Shatin Galleria

18-24 Shan Mei Street Fotan, Shatin, Hong Kong

**P** 852 2145 4099

F 852 2145 4477

