

TARGET FIELD PROJECTS BluRay Entertainment


This Document is a Project Overview Only

For Complete Instructions Visit the Field Projects Website

The project scope will vary depending on your store type.

P01 and P04 Stores

- You will be installing the endcap extension (MF2211) and the LCD mounting bracket (AX2523). The LCD mounting bracket contains a flash media player and plug strip.
- You will next attach the speaker bar (AX2480) to new NEC 3210 (AX2482) monitor.
- You will then mount this assembly on the mounting bracket, and make the proper connections to power and the flash player.
- Finally you will perform setup and testing of the display to ensure proper functionality.



In P04 stores the scope of work will be completed after the low voltage/electrical contractor is finished rewiring the store's media server distribution system. In P01 stores this will be done after the Facilities Management Tech finishes providing power to the gondola.

P09 Stores

The scope will be the same, but you will also be required to move the ceiling speaker over the Children's Entertainment monitor to a different location.

To determine what store type you have visit the Field Projects website. Once you have determined your store type you can print the correct Scope and Installation instructions for your store.

For Further Information:

If you find you are missing any parts please contact FP.FDR@target.com. If you have specific questions regarding installation email FacilitiesManagement.FieldProjects@target.com

FOR UPDATES AND FURTHER TROUBLESHOOTING PLEASE GO ONLINE AND FOLLOW THESE STEPS: Stores Workbench/Sales Floor/Electronics Interactive Display Troubleshooting/Blu-ray

8803-000115