



Ideas Supporting Ideas


UNIVERSAL SLIDE PROJECTOR STANDS

MODELS MSU-1000, MSU-1000B, MSU-2000 AND MSU-3000

MSU-1000 series MICRO-SET™ stands offer all the features of the MSU-100 and MSU-10 series, but are constructed of a heavier gauge aluminum cradle and a new yoke design with seven points of contact instead of three.

The MSU-1000 series is standard for the Kodak EK-III series projectors. With optional hold-down kits the MSU-1000 series will accommodate Kodak Ektrapro, Kodak EK-11, S-AV, Elmo, Telex/Singer, Simda and Apollo slide projectors.

With proper care your stand will provide years of reliable service. See special notes for important care and service tips.



Remove all packaging material, loosen small lock knobs on either side of each projector cradle and level cradles by rotating large outer knobs forward.

INSTALLING PROJECTORS

Four projector mounting supports, front and rear hold-down brackets are factory installed for the EK-III series projectors. (For projectors other than EK-III see additional instructions)

1. Fully retract all adjustable projector feet.
2. Fit projector into cradle; slide forward until the cradle stops against front stop bracket. Secure projector to stand by screwing hold-down knob through hole (1) snugly into threaded socket in the base of each projector, and by tightening rear brackets with rear hold-down knob.