
INSTALLATION INSTRUCTIONS

PLASMA DISPLAY STATIC MOUNT PSM-2540




Figure 1

- | | |
|--|----------------------------------|
| (1) Bracket, Plasma Mounting, Static | (1) Latching Flag |
| (4) Screws, M8 x 30mm Button Head Cap | (1) 10-24 x .5 FH Undercut Screw |
| (4) Mounting Buttons, Nylon stepped, pan style | (1) Nylon Washer |
| (1) Allen Key, 5mm | (1) 10-24 Nylock Nut |

BEFORE PROCEEDING: Unpack the carton, verify contents shown in Figure 1 and read installation instructions completely. If you are missing any of the listed components, please contact Customer Service at 1-800/582-6480.

CAUTION! Plasma Displays are Extremely Fragile.



WARNING! ALL COMPONENTS MUST BE SECURELY FASTENED TO A STRUCTURAL MEMBER CAPABLE OF SUPPORTING 4 TIMES THE COMBINED WEIGHT OF ALL COMPONENTS PLUS THE EQUIPMENT BEING MOUNTED. IF IT CANNOT SUPPORT THIS WEIGHT, THE STRUCTURE MUST BE REINFORCED. THE MAXIMUM WEIGHT TO BE INSTALLED ON THE MOUNT IS 175 POUNDS (79.38 KG).

1. Attach four mounting buttons to display using four M8 x 30mm button head cap screws provided (see Figure 2).
2. Secure latching flag to Plasma Static Mount using one 10-24 x .5 FH undercut screw, one Nylon washer, and one 10-24 Nylock nut (see Figure 3).



CHIEF MANUFACTURING INC.
1-800-582-6480 952-894-6280 FAX 952-894-6918
8401 EAGLE CREEK PKWY, STE. 700
SAVAGE, MINNESOTA 55378 USA

8805-000097 REV. B
2004 Chief Manufacturing
www.chiefmfg.com
10/04



3. Securely anchor the plasma static mount to the wall using wall studs or supporting framework (see Figure 4).
4. Make sure the flag is lowered to the side before attempting to place the display on the mount.
5. With the aid of another person, lift the display up to the mount, align the mounting buttons on the display with the teardrop slots in the mount, and set the display into place.
6. Position (raise) the flag to secure the display.

