



SLB-1020 HANGER BRACKET FOR LIGHTWARE L-1020

Unpack carton and check contents:

- | | | | |
|-----|---------------------------|-----|------------------|
| (1) | SLB 1020 Bracket | (4) | M4 Flatwashers |
| (1) | SLB 1020 Security Clip | (6) | 10-24 Thumb Nuts |
| (4) | M4 x 12 mm Machine Screws | | |

Installation Instructions

1. Turn projector upside down.
2. Raise two 1¼" diameter adjustable rear feet up about one inch.
3. Attach security clip to hanging bracket using two M4-7 x 12 mm screws and lock washers. Screw head should be on top side of flange.
4. Slide hanging bracket between raised threaded studs of rear adjustable feet as you also align the security clip into an 1/8" x 3/8" slot located upper left of lens at front edge of projector.
5. Align two .20" diameter holes at rear of hanging bracket with M4 inserts located between adjustable feet and slightly forward of them. Install two M4-7 x 12 mm long screws and tighten slightly. **CAUTION! When attaching mount and installing screws be careful not to over tighten.**
6. Lower two adjustable feet against hanging bracket and tighten slightly.
7. See RPA instructions for installing the assembled hanging bracket and projector to an RPA. Also see RPA instructions for adjusting roll, pitch, and yaw. See general exploded view below.