



SLB-4700 Hanger Bracket for Philips LC4700G LC4750

Unpack carton and check contents:

(1)	SLB-4700	(2)	U-Form Rods
(4)	10-24 Nylock Nuts	(4)	#10 Flatwashers
(8)	Felt Squares	(6)	Thumb Nuts

Installation Instructions

1. Turn projector upside down.
2. Bracket should be centered on projector. Attach the U-Form rods around the projector and up through the holes in the SLB-4700 plate; secure to projector using the #10 Flatwashers and 10-24 nylock nuts.
(Do not over tighten, you may damage or affect projector from running correctly.)
Note: Felt squares are provided to protect projector shell, if desired. They can be attached to the projector or wrapped around the U-Form rod.
3. See RPA/SMART-LIFT™ Instructions.