



INSTALLATION INSTRUCTIONS

SLB-700 HANGER BRACKET


for EPSON EMP-500C, EMP-503C, EMP505C, EMP-700C,
EMP-703C, EMP710C, EMP713P, EMP-715C,

Prior to assembly, unpack carton and verify contents.

For security installation, use security hardware package inside the ALL-POINTS™ Security Kit. Follow the instructions below for attaching the bracket to the projector using either standard hardware or security hardware.

If you are missing any of the following components, please contact Customer Service at 1-800-582-6480

- | | | | |
|-----|--------------------|-----|-----------------|
| (1) | SLB-700 Bracket | (3) | M3 Flatwashers |
| (3) | 10 - 24 Thumb Nuts | (3) | M3 -10mm screws |



INSTALLATION INSTRUCTIONS

1. Turn projector upside down.
2. Place SLB-700 plate onto bottom of projector. Line up the three mounting holes in the SLB-700 plate with the three threaded inserts and secure using the three M3 -10mm mounting screws and M3 Flatwashers. **CAUTION: When attaching the mount be careful not to overtighten.**
3. See RPA and/or Smart-Lift™ Instructions.