

# INSTALLATION INSTRUCTIONS


## SSB-1120, SSM-1120, SLB-1120 and SLM-1120 Interface Brackets

SSB-1120, SSM-1120, SLB-1120 and SLM-1120 Interface Brackets are designed for use with Chief® Series Projector Mounts. See the specific installation instructions provided with the mount for additional installation information.

Unpack carton and verify kit contents. If any listed parts are missing, immediately contact a Chief Customer Service representative.

**WARNING: IMPROPER INSTALLATION CAN LEAD TO EQUIPMENT FALLING CAUSING SERIOUS PERSONAL INJURY AND DAMAGE TO EQUIPMENT! DO NOT substitute hardware. Use only hardware supplied by manufacturer!**

- |                             |                     |
|-----------------------------|---------------------|
| (1) Interface Bracket       | (2) M4 -10mm Screws |
| (4) 10 - 24 Thumb Nuts**    | (2) M3 - 6mm Screws |
| (1) All-Points Security Kit | (2) M4 Flat Washers |
| (4) Rubber Bump-on          | (2) M3 Flat Washers |



\*\*Only used when installing SLB/SSB interface brackets.

**NOTE:** Specific to SSB-style and SSM-style interface bracket installation, all appropriate screws come pre-installed as reflected in the encircled locations above. DO NOT attempt to substitute and USE ONLY this pre-installed hardware for SSB-style and SSM-style interface bracket installation.

### Installation Instructions

**WARNING: OVER TIGHTENING OF SCREWS CAN DAMAGE PARTS AND CAN LEAD TO SERIOUS PERSONAL INJURY AND DAMAGE TO EQUIPMENT! DO NOT over tighten screws when installing Interface bracket.**

**NOTE:** Step 1 is only required when installing an SLB/SSB interface bracket. If an SLM/SSM bracket is being installed, proceed to step 2.

1. Screw thumb screws onto 10-24 x 5/8" Phillips pan head screws. DO NOT fully tighten thumb screws at this time.
2. Turn projector upside down.
3. Push the four-rubber bump-on's through the four larger holes in the bracket from the side with the inside bend.
4. Place the interface bracket onto the bottom of the projector and align the mounting holes with the threaded inserts in the bottom and back of the projector.
5. Using the M4 -10mm mounting screws and M4 flat washers on the bottom holes and the M3 - 6mm mounting screws and M3 flat washer on the back holes, secure interface bracket to projector and tighten all fasteners at this time.

**NOTE:** Security screws can be substituted when mounting interface bracket to projector by using the parts and installation instructions in the All-Points Security Kit.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.



Milestone AV Technologies, and its affiliated corporations and subsidiaries (collectively, "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.



Our Mounts. Your Vision.

Chief Manufacturing, a products division of Milestone AV Technologies  
8401 Eagle Creek Parkway, Savage, MN 55378

• P: 800.582.6480 / 952.894.6280 • F: 877.894.6918 / 952.894.6918

8802-000060 Rev01

©2009 Milestone AV Technologies,  
a Duchossois Group Company

05/09