

SV-1 LCD/DLP PROJECTOR STAND

Unpack carton and check contents:

A- (1) Caster Base	F- (1) 2¼" Washer	K- (1) ¼"- 20 x 2½" Carriage Bolt
B- (5) 2" Casters	G- (1) 5/16" x 3" Bolt	L- (1) Thumb Knob
C- (1) Table w/Adj. Plate	H- (1) Lock Washer	M- (1) ¼" x 2½" Bolt
D- (1) Outer Tube, 24¼" L	I- (1) 5/16" x 3" Thumb Bolt	N- (1) ¼" Nut
E- (1) Inner Tube, 25½" L	J- (2) 5/16" Flat Washer	O- (3) ¼" Washer
		P- (1) 3/8" Bushing
		Q- (1) 2 1/16" ID Support Ring

INSTALLATION INSTRUCTIONS

1. Lay the 18" x 24" table upside down on work surface exposing the tabs. Insert the 3/8" x 1¾" bushing into the end of the tube. Lay the inner tube between the vertical tabs. Align the tab holes, tube holes and the bushing. Insert the ¼" - 20 x 2½" bolt through the assembly and tighten. Tighten upper bolt until it is snug against the tube, before inserting ¼-20 x 2½", carriage bolt with thumb knob. See exploded view & detail.
2. Invert five/leg base and install outer tube into base center opening. Lay 2 1/16" id x 3/8" high support ring around base flange. Lay 2 ¼" dia. large washer over support ring. Thread 5/16" x 3" bolt with lock washer through hole in washer and into internal clip of tube. Slowly draw assembly together, assuring that it is properly seated into base.
3. Install the five casters into the base and set it on the floor.
4. Insert inner tube and table assembly into lower, outer tube
5. Adjust height positions by alternately loosening and tightening the pre-assembled thumb bolt after lifting the table to the desired height.
6. Adjust table pitch angle by loosening the upper thumb knob only and tilting it in the slotted hole and re-tightening.



CHIEF MANUFACTURING INC.

1-800-582-6480 952-894-6280 FAX 952-894-6918

12800 HIGHWAY 13 SOUTH, SUITE 500

SAVAGE, MINNESOTA 55378 USA

8807-000013

2003 Chief Manufacturing

www.chiefmfg.com

01/04