

## SV-104 LCD/DLP PROJECTOR STAND

Unpack carton and check contents:

(1)	Steel Base	(4)	<sup>5</sup> / <sub>16</sub> " Keep Nuts
(2)	2" Swivel Castors	(4)	1" x 1" Caplugs
(2)	2" Swivel Castors w/Brakes	(1)	Shelf Assembly
(1)	TPL Telescoping Post Assembly		

### ASSEMBLY INSTRUCTIONS

1. Lay the steel base down with the caster holes facing up. Install the casters with brakes next to each other on the eighteen inch width of the base. Hold a nut in the inside of the leg and thread the caster stem into the nut. **Tighten securely** using a  $\frac{1}{2}$ " wrench. Install the remaining two casters in the same manner. **(CAUTION: Casters must be tightened securely to base to prevent any damage to cart or equipment.)** Install the caplugs.
2. Install black column into base. **Tighten post securely** with knob. **NOTE: DO NOT severely overtighten the knobs, to avoid denting or deformation of the posts.**
3. Place the shelf over the post and **securely tighten** both knobs against the post. **NOTE: DO NOT severely overtighten the knobs, to avoid denting or deformation of the post.**
4. To operate the pitch, simultaneously loosen one knob and tighten the other to move the shelf. When the shelf is correctly positioned, **tighten each knob securely.**

**CAUTION:** Care must be taken to adjust both knobs at the same time. If one knob is loosened without the opposing knob being tightened, the shelf may suddenly tip, resulting in possible serious personal injury or equipment damage.



**CHIEF MANUFACTURING INC.**

**1-800-582-6480 952-894-6280 FAX 952-894-6918**

**12800 HIGHWAY 13 SOUTH, SUITE 500**

**SAVAGE, MINNESOTA 55378 USA**

8807-000014

2003 Chief Manufacturing

[www.chiefmfg.com](http://www.chiefmfg.com)

01/04