

INSTALLATION INSTRUCTIONS

ELEPHIL-PRO(L) Mounting Bracket

Prior to assembly, unpack carton completely and verify contents. If you are missing any of the following components, please contact Technical Support at 1-800-776-5768.

- (1) PLASMA STATIC BRACKET
- (4) MOUNTING BUTTONS
- (2) M10-1.5 X 20mm HHCS
- (4) 10-24 Flat head Cap Screws
- (2) M10 Flat Washer
- (1) 1/8" Allen Key



Figure 1

CAUTION: PLASMA DISPLAYS ARE EXTREMELY FRAGILE!

BEFORE PROCEEDING, READ INSTALLATION INSTRUCTIONS COMPLETELY

1. Insert a 10-24 flat head cap screw into chamfered hole side of bracket (see Figure 2).
2. Secure mounting button, with chamfered hole of mounting button (larger surface) facing bracket, to bracket and repeat step 1 and 2 for all four mounting buttons.
3. Slide bracket lip into aluminum extrusion and place bracket gently down onto plasma (see Figure 2).
4. With plasma bracket resting on plasma, push bracket towards the top of the plasma to fully engage in aluminum extrusion and secure using two hex head bolts and M10 flat washers (included). Be careful not to over tighten bolts.
5. With the aid of another person, lift Plasma Display up to the mount, aligning buttons of mounting brackets with slots in the mount.
6. Lower safety catch on the mount to secure Plasma Display, making sure catch is completely engaged.



Figure 2