

# CM1 CALIBRATION INSTRUCTIONS

## CALIBRATION PROCEDURE

### Learning the Sensor Locations

**NOTE:** Make sure there is no load on the unit when performing the following steps. Any load on the unit may cause the calibration procedure to fail.

1. Turn power on to the CM1.
2. Press top middle button (2) of the remote to begin the calibration. (See Figure 1)

**NOTE:** This step will take a few minutes while the system detects all the sensor positions. This step is complete when the unit returns to the "home" position.

### Setting New Center Position

3. Center the swivel mechanism using the left (4) and right (6) buttons on the remote. (See Figure 1)

**NOTE:** Centering the swivel mechanism can also be done using the swivel buttons (10 and 12). However, it is more difficult to accurately center the swivel mechanism.

4. Once you reach the center position, press "Set" (27) three times.
5. Press "Preset" (19).
6. Press "Home" (3).

**NOTE:** The unit will move slightly to indicate the new "Home" position was saved successfully.




Figure 1:

CSAV, Inc., and its affiliated corporations and subsidiaries (collectively, "CSAV"), intend to make this manual accurate and complete. However, CSAV makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. CSAV makes no representation of warranty, expressed or implied, regarding the information contained herein. CSAV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.