

---

# INSTALLATION INSTRUCTIONS


---

## MOUNTING PLATE

### CMA-150

The CMA-150 mounting plate allows you to attach the Smart-Lift (Models SL-100 and SL-150) to a standard NPT 1½” pipe thread (compatible with CMA-100 and CMA-110) for suspended ceiling mount applications.


**WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY!**  
When mounting Chief Manufacturing accessories, the structural system and mounting method **MUST** be capable of supporting 5 times the combined weight of the total installation.



Unpack and check contents:

- |                             |                                 |
|-----------------------------|---------------------------------|
| (1) PLATE, Mounting, Top    | (1) SCREW, Set, Socket, 5/16-18 |
| (1) PLATE, Mounting, Bottom | (1) WRENCH, Allen, 5/32”        |
| (4) NUT, Flange, 5/16-18    |                                 |

1. Attach bottom mounting plate to Smart-Lift by opening unit (tray in down position) and placing bottom mounting plate up into the Smart-Lift cover (studs in plate through slotted holes).
2. Place top mounting plate over protruding studs of bottom mounting plate and secure using four flange nuts.
3. See Smart-Lift instructions.



**Figure 1. CMA-150 Installation**



**CHIEF MANUFACTURING INC.**  
1-800-582-6480 952-894-6280 FAX 952-894-6918  
12800 HIGHWAY 13 SOUTH, SUITE 500  
SAVAGE, MINNESOTA 55378 USA

8803-000012  
2002 Chief Manufacturing  
[www.chiefmfg.com](http://www.chiefmfg.com)  
10/02