
INSTALLATION INSTRUCTIONS

CVI42-SM Static Wall Mount

Prior to assembly, unpack carton completely and verify contents. If you are missing any of the following components, please contact Technical Support at 1-800-776-5768.



- (1) PLASMA STATIC WALL MOUNT
- (2) LATCH, SAFETY
- (4) MOUNTING BUTTONS-NYLON
- (2) NYLON WASHER
- (1) M5 ALLEN KEY
- (2) 10-24 X .5 FH UNDERCUT SCREW
- (2) 10-24 NYLOCK NUT
- (4) M8 X 40MM BUTTON HEAD CAP SCREWS

CAUTION: PLASMA DISPLAYS ARE EXTREMELY FRAGILE!

READ INSTALLATION INSTRUCTIONS COMPLETELY BEFORE PROCEEDING




Figure 2




Figure 3




Figure 4




Figure 5

1. Using two 10-24 x .5 FH undercut screws, Nylon washers between safety latch and mount, and 10-24 Nylock nuts, install the safety latches on the inside holes loose enough to move but tight enough to remain in place when raised (see Figure 2).
2. Attach mounting buttons to display using M8 bolts and tighten using Allen key included (see Figures 3 & 4).
3. Securely anchor the mount to the wall using wall studs or supporting framework.

Warning! THE MOUNT, WHEN ANCHORED IN PLACE, MUST BE CAPABLE OF SUPPORTING 4 TIMES THE COMBINED WEIGHT OF THE PLASMA AND MOUNT.

4. Make sure the flags are lowered to the side before attempting to place the display on the mount.
5. With the aid of another person, lift the display up to the mount, align the mounting buttons on the display with the teardrop slots in the mount, and set the display into place (see Figure 5).
6. Position (raise) the flag to secure the display (see Figure 5).

Champion

PART NO. CVI42-SM
©2003
Printed in USA 10-03
