



INSTALLATION INSTRUCTIONS

PSB-2170

PLASMA DISPLAY MOUNTING BRACKET

Prior to assembly, unpack carton completely and verify contents.

If you are missing any of the following components, please contact Customer Service at 1-800/582-6480




Figure 1

- (1) Plasma Static Mount Left Bracket
- (4) Mounting Buttons
- (6) M4 x 16mm Philips Head Screw




Figure 2

- (1) Plasma Static Mount Right Bracket
- (4) 10-24 Flat head Cap Screws
- (1) 1/8" Allen Key
- (6) Nylon Shoulder Washer

BEFORE PROCEEDING, READ INSTALLATION INSTRUCTIONS COMPLETELY

CAUTION! PLASMA DISPLAYS ARE EXTREMELY FRAGILE.

1. Using a 10-24 flat head cap screw inserted from chamfered hole side of bracket, secure mounting button, with chamfered hole of mounting button (larger surface), to bracket (four places) (see Figure 1)
2. Attach mounting brackets to display as shown using the M4 Philips head cap screws with one shoulder washer under the head of the screw (see Figure 3 & Figure 4)
3. With the aid of another person, lift the display up to the Chief Mount, aligning buttons of mounting brackets with slots in the Chief Mount.
4. Lower safety catch on the Chief Mount to secure the display, making sure catch is completely engaged.




Figure 3




Figure 4