



INSTALLATION INSTRUCTIONS FOR KAR and GAR

ALL DOORS AND ACCESSORIES THAT REQUIRE GROUNDING MUST HAVE GROUND WIRES FIELD INSTALLED. ALL PARTS ARE PROVIDED.

NOTE: ALL DOORS AND ACCESSORIES MUST BE GROUNDED FOR UL COMPLIANCE.

CAUTION - TO REDUCE THE RISK OF PERSONAL INJURY AND CONFORM TO THE UL LISTING, THESE INSTALLATION INSTRUCTIONS MUST BE FOLLOWED

All Raxxess racks are EIA Compliant and provide up to 2500 lbs without wheels.

Door Grounding - The door ground stud is located next to the bottom hinge pivot pin. Using the ground wire and kep nut provided, attach one end of the ground wire to the door grounding stud and the other end to the base ground stud located on the inside bottom corner of the rack.
(Refer to pictures below)

Rail Grounding - Using the ground wire, kep nut, and bolt provided, attach one end of the ground wire to the bottom rail hole and the other end of the ground wire to the base ground stud which is located on the inside bottom corner of the rack.
(Refer to pictures below)

Leveling - All free-standing racks must be plumb and level. (Refer to pictures below)

Wire Entry - Numerous knock-outs are provided for wire entry. All knock-outs that are used for wires without conduit must have bushings inserted in the knock-out to eliminate damage to the cable's insulation.

Thermal Management - It is important heat generating equipment have adequate spacing between units for proper air flow. Many different types of panels can be purchased for the thermal management (cooling) of your rack. Perforated metal panels provide additional convection cooling. Fan panels are also available for forced air cooling. **It is important to maintain an operating temperature inside the rack that does not exceed 40 degrees C (104 degrees F)**



NOTE: ALL RACK ASSEMBLY AND INSTALLATION IS TO BE DONE BY QUALIFIED SERVICE PERSONNEL.